

FlareAlert Accessories



Weighted Base



The rotor wash created by a landing helicopter can reach up to 150 mph. The Universal Weighted Base will keep your FlareAlerts in place.

All FlareAlert models are magnetic, so they will stick magnetically to the Universal Weighted Base. This accessory allows you to utilize all FlareAlert models to mark a landing zone for a helicopter.

The Universal Weighted Base fits all models of FlareAlert (FlareAlert, Beacon, and Beacon Pro).



Cone Adaptor



Need to place your FlareAlerts on top of a cone? No problem. Our Universal Cone Adaptor slides into the top of a cone.

The magnets in your FlareAlert adhere it to the Universal Cone Adaptor, increasing visibility. Simply attach your FlareAlert to the Universal Cone Adaptor and drop it into the top of any standard cone.

The Universal Cone Adaptor fits all models of FlareAlert (FlareAlert, Beacon, and Beacon Pro).



The Universal Cone Adaptor secures 1-2 FlareAlerts to the top of a cone.

Ground Stand

No cone, no problem



When used together, the Universal Cone Adapter screws into the Universal Weighted Base to form a third accessory...the Ground Stand.

The Ground Stand allows you to elevate the FlareAlert when you don't have a cone or magnetic surface available. Elevating the FlareAlert makes it more visible, and less susceptible to being obstructed by snow, grass, or other objects.



Want to light up your cone without the use of accessories? Place your FlareAlert underneath the cone to make it glow. Now the cone is visible before being illuminated by a vehicle's headlights.